



|                           |  |   |
|---------------------------|--|---|
| 50200800                  | <b>SHORT INSTRUCTION</b>                             |  |
| Valid from:<br>18.07.2018 | ZYLIN <sup>®</sup> R 3.0 ASSEMBLY / DISASSEMBLY TOOL |   |


Short instruction how to use the EPIC<sup>®</sup> tool 50200800 and assemble the cable connector ZYLIN<sup>®</sup> R 3.0

### Type D




**Attention: The insulation body and contacts are fixed in the contact case!**

|  |   |
|--|---|
|  | <p>1. Fix the nib of the contact case with the notch of the assembling tool</p> |
|  | <p>2. Lead the coupling nut over the contact case.</p>                          |
|  | <p>3. Lead the clutch housing on the contact case.</p>                          |
|  | <p>4. Screw the clutch housing on the contact case.</p>                         |

|                           |  |   |
|---------------------------|--|---|
| 50200800                  | <b>SHORT INSTRUCTION</b>                             |  |
| Valid from:<br>18.07.2018 | ZYLIN <sup>®</sup> R 3.0 ASSEMBLY / DISASSEMBLY TOOL |   |

Short instruction how to use the EPIC<sup>®</sup> tool 50200800 and assemble the cable connector ZYLIN<sup>®</sup> R 3.0

## Typ F



CLUTCH HOUSING R3.0 D/F-TYPE

Contact case R3.0 DESIGN F KPL.

ASSEMBLING TOOL

**Attention: The insulation body and contacts are fixed in the contact case!**

|  |   |
|--|---|
|  | <p>1. Fix the notch of the contact case with the nib of the assembling tool</p> |
|  | <p>2. Lead the clutch housing on the contact case.</p>                          |
|  | <p>3. Screw the clutch housing on the contact case.</p>                         |